

E-DRUMS AMP ADX-30

Owner's manual

Thank you for purchasing Aroma E-drums Amp ADX-30.

AROMA®

© 2022 Aroma Music Co., Ltd.

WARNING! - IMPORTANT SAFETY INSTRUCTIONS


▲ Please pay much attention to the following before using the amp

1. Use only the power cord attached. If you are purposed to replace the power code, please consult qualified electricity personnel or your dealer.
2. Never break off the ground pin on the power supply plug.
3. Never attempt to by-pass the fuses or replace the fuse with incorrect value.
4. Do not attempt to repair this product by yourself, as that opening or removing the amp covers may expose you to dangerous voltage points or other risks. Refer all services to qualified service personnel.
5. If any of below happened, please repair the amp by a qualified personnel, such as that the power cord damaged, or the power plug damaged, or liquid or metal parts been into the amp, or the amp been exposed to rain or moisture, etc..
6. Do not use or store the amp in circumstances of high humidity.
7. The amp is not water-proof, do not place any container with liquid on the amp.
8. The power cord should be unplugged if the amp is not to be used for a long period of time.
9. Protect the power cord from being walked on or pinched for safety.
10. Make sure that the electricity outlet, which connected to the amp power plug, is grounded.


Keep this manual for later references.

PANEL CONTROLS AND FUNCTION

Front Panel



Rear Panel



1. Drum Sound Input---Signal input from electronic drums ,6.35mm gauge jack
2. Drum Sound Input-----Signal input from electronic drums ,3.5mm gauge jack
3. AUX Sound Input -----Signal input, 3.5mm gauge jack
4. Drum Volume-----Knob to control drums sound volume
5. Aux Volume-----Knob to control music volume
6. Drum Bass -----Knob to control low frequencies level
7. Drum Treble -----Knob to control high frequencies level
8. Bluetooth ----- Bluetooth ON/ OFF
9. Power ----- Power switch
10. Power Socket -----Power socket

▲ **WARNING:** This product is only suitable for one working voltage, please check whether the local AC voltage is consistent with the voltage range marked on the back of the product before using it. Wrong voltage may cause malfunction.

BLUETOOTH FUNCTION

To connect bluetooth, press and hold the amp bluetooth button till that the bluetooth LED light is up. Turn on the bluetooth function on the mobile phone and automatically search for bluetooth devices. If the device name of "ADX-30 AUDIO "is found, it means that the device has been found. Please click to connect. When the connection is successful, a "di" sound will be heard.

SPECIFICATIONS

Power: 30W
Input: 220V~50Hz
Consumption: ≤50W
Speaker: 6.5 inch woofer + 2.5 inch tweeter
Bluetooth version: 5.0
Net weight: 7.6kg
Product dimension: 389x326.5x284mm
Package dimension: 450x405x350mm
Packing list: ADX-30 x1, AC cable x1, manual x1

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which there receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

aromamusic.cn

follow us

facebook.com/AromaMusicGear

info@aromamusic.cn

Designed and engineered by AROMA MUSIC



电子鼓专用音箱ADX-30

使用说明书

非常感谢您购买AROMA牌电子鼓音箱ADX-30。请在使用本产品前，仔细阅读使用说明书。

AROMA®

咨询电话:0752-3189101
广东省惠州市惠阳区淡水街道古屋村阿诺玛工业园A栋

© 2022 深圳市阿诺玛乐器有限公司

aromamusic.cn

警告事项! 重要的安全事项


▲ 使用之前请阅读下述注意

1. 请使用随机附带的电源线，如要更换电源线请在专业人员指导下使用经过确认的电源连接线。
2. 不要将电源线插座中间的插脚去掉！
3. 不要试图短接电源座内部的保险或是使用非正确的保险管。
4. 不要自行维修机器！打开机箱可能将您的身体暴露于危险电压或其他危险情况之下。如需维修或维护请有资质的维修人员进行服务。
5. 如果您是具有维修资质的服务人员请注意：
设备在任何被损坏的情况都需要进行维修服务，这其中包括诸如：电源线破损断裂，插座头损坏，液体或固体流入或落入机器设备内部，设备被放置在潮湿或雨水环境当中等造成机器不能正常工作的情况。
6. 不要将音箱置于潮湿的环境储存或使用！
7. 设备不应受水滴飞溅，设备上不应放置诸如花瓶类的装满液体的物品。
8. 当设备长时间不用的情况下请将电源线从电源插座上拔下。
9. 当需要插入电源线到插座时，确保远离人们行走的通道。使用完毕及时收纳并妥善保管好电源线。
10. 确保音箱所使用的环境处供电插座已经进行了妥善的接地处理。


阅读完此说明书后，请保留以备后用。

面板功能介绍

前面板



后面板



1. 鼓通道.....电子鼓音源6.35mm输入插孔
2. 鼓通道.....电子鼓音源3.5mm输入插孔
3. AUX通道.....外接信号音源3.5mm输入插孔
4. 鼓通道.....鼓通道音量调节旋钮
5. AUX通道.....AUX通道音量调节旋钮
6. 低音.....低音调节旋钮
7. 高音.....高音调节旋钮
8. 蓝牙.....蓝牙开关
9. POWER.....电源开关
10. AC插座.....AC220V电源线输入

▲ 警告：本产品仅适应一种工作电压，通电使用前请核对本地交流电压是否和产品背面标注的电压范围一致，若不一致时请勿通电，否则可能会引起产品损坏或无法正常工作。

蓝牙功能

蓝牙与手机连接时，先长按蓝牙开机按键(📶)，此时蓝色LED点亮，表示蓝牙已启动。手机端开启蓝牙功能并会自动搜寻蓝牙设备，若搜索到“ADX-30 AUDIO”设备名时，表示已搜寻到本设备，请点击连接，当蓝牙连接成功时，本产品会发出“滴”的提示音。

产品参数

额定功率: 30W
输入: 220V~50Hz
功耗: ≤50W
喇叭单元: 6.5寸低音喇叭+2.5寸高音喇叭
蓝牙版本: 5.0
产品净重: 7.6kg
产品尺寸: 389x327x284mm
包装尺寸: 450x405x350mm
产品装箱清单: ADX-30音箱x1, AC电源线x1, 说明书x1, 合格证x1。

